

Wired Gamepad USB Firmware Update Instruction

1. Open the firmware ;



2. Press and hold the right + L3 at the same time while connecting the USB like the following picture show.

3, Press UPDATE button when it' s ready to update firmware



PS : Please repeat the Step 2 (Disconnect USB Cable , Press and hold RIGHT + L3 at the to enter the upadte page while connecting the USB) if appear the follow page.



4. Updating..Do not remove the controller



5. Update successful, can disconnect USB cable.



PS: Please ensure the USB cable is good or not disconnected USB cable during updating

